

Linens

Our linens are made with luxurious 100% combed cotton and poly/cotton blends. These linens will maintain their original beauty for a long period of time if cared for properly. Please follow these recommendations carefully and consult with your local laundering experts. Each facility is unique so an initial test run should be done at the local level and make adjustments accordingly.

DO'S

- Sheet duvets should be inside out before laundering
- Wash and dry in warm temperature, not exceeding 170°F (77°C)
- Wash with mild surface detergent.
- Use gentle cycle in washing and drying
- Wash and dry separately from other textiles
- Check for burrs inside the washing machine and dryer periodically and smooth out the roughness inside the machines before putting in any other products
- Remove the items from the washer and dryer as soon as the cycle is over
- Test ONE set in a washer and dryer for a satisfactory result. Proceed with others when the test result is satisfactory. (Koni Hospitality will be responsible for one test set only, if an unsatisfactory result occurs)
- The inside out Sheet Duvet should be run through the calender machine first

DON'TS

- **DO NOT** use HOT water exceeding 170°F (77°C)
- **DO NOT** use HOT temperature in dryer exceeding 120°F (49°C)
- **DO NOT** use Alkaline detergent
- **DO NOT** use chlorine bleach
- **DO NOT** use fabric softener in either the washing or drying cycles
- **DO NOT** mix with different textiles or products while laundering
- **DO NOT** use washing machines or a dryer with burrs inside

Koni PreClean Spot Remover

Apply Koni PreClean Spot Remover to the spot and gently rub it into the fabric. Allow it to stand for 10 minutes. Hands wash the spot in lukewarm water, then follow the washing and drying instructions. Most of the stains will be removed with this application, but if you run into a stubborn stain, brush lightly after applying PreClean and repeat the process.